

zipfracer

GENERAL WARNINGS (EN)

General Product Safety Regulation – (EU) 2023/988 – 10/05/2023



General:

1. The Zipfracer can only be used on a sufficiently snow-covered surface. Riding on sand, concrete, stones, asphalt, water, grass etc. can cause severe damage to the product.
2. The Zipfracer should not be ridden while attached to vehicles of any kind.
3. Sleigh riding can be dangerous! It can cause injuries while using this product and /or to third parties. Unforeseen and dangerous situations can occur. Do not overestimate your abilities. Do not use the Zipfracer if you are feeling unwell, are injured or under the influence of alcohol, medication or drugs.
4. The producer does not take any responsibility for physical damages or damages to the product that are caused through an incorrect use of the product.

Security:

1. The Zipfracer is made for teenagers and adults and should not be used by persons smaller than 1,50 meters.
2. The Zipfracer should only be ridden by one person.
3. The maximum load should not exceed 130 kg.

2962 GmbH
Alter Messeplatz 4
Hinterhof
80339 München
Germany

Rechtsform: GmbH
Sitz: München HR 169678
Steuer-Nr.: 143/194/90753
USt-IdNr.: DE255860626

Email:
info@zipfracer.com

Maintenance, Care and Storage:

1. The Zipfracer should be checked from time to time for any damages or general wear and tear.
2. As soon as there are damages the Zipfracer should no longer be used. Other maintenance is not necessary.
3. The body and the gear stick of the Zipfracer can be cleaned with generic household cleaners.
4. The seat cushion should not be cleaned with solvent cleaners, high pressure cleaners, heating devices or sharp objects.
5. Before using cleaning products, it is recommended to test on a small spot.
6. The Zipfracer should not be placed near fire, heating units or any other heating sources.
7. Do not leave the Zipfracer outside for prolonged periods, especially in sunlight. The Neon Colors are not UV stable.

Before Riding:

1. We recommend using heavy, waterproof shoes, ski mask, gloves and helmet while riding.
2. When riding at night or in the dark, please ensure that you have sufficient lighting with you such as a head lamp.

Riding:

1. In order to ride, sit comfortably on the seat, the thighs resting on the heightened top surface. The gear stick should be in the middle, between the legs.
2. In order to steer, a slight shift in weight onto the respective side is sufficient. You can also reach into the snow quickly (one hand remaining on the gear stick). The legs should be parallel and extended. Alternatively, one can also steer by putting the hands in the grip next to the legs. In order to break simply pull the gear stick up slightly and come to a halt.
3. In order to increase the speed, it is recommended to move your body weight as far back as possible.